

ZTE Blade C310 Mobile Phone Quick Start Guide

LEGAL INFORMATION

Copyright © 2014 ZTE CORPORATION.


All rights reserved.

No part of this publication may be quoted, reproduced, translated or used in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation.

ZTE Corporation reserves the right to make modifications on print errors or update specifications in this guide without prior notice.

Trademarks

ZTE and the ZTE logos are trademarks of the ZTE Corporation. Google and Android are trademarks of Google, Inc. The *Bluetooth*® trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such trademarks by ZTE Corporation is under license.

 microSDHC Logo is a trademark of SD-3C, LLC.

Other trademarks and trade names are the property of their respective owners.

We offer self-service for our smart terminal device users. Please visit the ZTE official website (at www.ztedevice.com) for more information on self-service and supported product models. Information on the website takes precedence.

Visit <http://www.ztedevice.com> to download the user manual. Just click **Support > Manuals** from the home page and then select your location, product type, and name to search for related support information.











Disclaimer









ZTE Corporation expressly disclaims any liability for faults and damages caused by unauthorized modifications of the software.

Version No. : R1.0



Edition Time : 2015.02.03

Product Safety Information

	Do not use hand-held while driving
	For body-worn operation maintain a separation of 15 mm
	Small parts may cause a choking hazard
	This device may produce a loud sound
	Avoid contact with magnetic media
	Keep away from pacemakers and other personal medical devices
	Switch off when instructed in hospitals and medical facilities
	Switch off when instructed in aircrafts and airports
	Switch off in explosive environments
	Do not use while re-fuelling

	This device may produce a bright or flashing light
	Do not dispose of it in a fire
	To prevent possible hearing damage, do not listen at high volume levels for long periods.
	Avoid Extreme Temperatures
	Avoid any contact with liquid, keep it dry
	Do not attempt to disassemble
	Only use approved accessories
	Do not rely on this device for emergency communications

Getting to Know Your Phone



Power Key

- Hold to turn on or off Silent or vibrate or Airplane mode, or to power off.
- Press to switch your phone to Sleep mode.
- Press to wake up your phone.

Home Key

- Press to return to the Home Screen from any application or screen.
- Hold to see Google search.

Menu Key

- Press to get the options for the current screen.
- Hold to see recently used applications.

Back Key


- Press to go to the previous screen.

Volume Up/Volume Down


- Press or hold to turn the volume up or down.

Starting Up

1. Removing the Back Cover




2. Installing the SIM Card



Notes:


- Switch off your phone before installing or replacing the SIM card.
- If you're using a small card, please buy standardization SIM dedicated card sets from the formal channels, and then push the whole into the slot.

3. Installing the microSD Card



Notes: Some applications may require a microSD card to work normally or may store certain data on it. Therefore, it is recommended that you keep a microSD card installed and not remove or replace it randomly.

4. Charging the Battery



When you first get your new phone you'll need to charge the battery like this:

1. Connect the adapter to the charging jack.
2. Connect the charger to a standard AC power outlet.
3. Disconnect the charger when the battery is fully charged.

Notes: If excessive discharge of the battery, the charging icon will display delay.


CAUTION: Do not change the built-in rechargeable battery in your phone by yourself. The battery can only be changed by ZTE or ZTE authorized service provider.

Powering On/Off Your Phone

Make sure the battery is charged before powering on.

- Press and hold the **Power Key** to turn on your phone.
- To turn it off, press and hold the **Power Key** to open the options menu. Touch **Power off**>OK.

Waking Up Your Phone

1. Press the **Power Key** to activate your screen display.
2. Drag the  icon to the right to unlock.

Notes:

If you have set an 'unlock pattern', or a PIN/password for your phone, you'll need to draw the pattern or enter the PIN/password to unlock your screen.

Using the Touch Screen

Your phone's touch screen lets you control actions through a variety of touch gestures.

• Touch

When you want to type using the onscreen keyboard, select items onscreen such as application and settings icons, or press onscreen buttons, simply touch them with your finger.

• Touch and Hold

To open the available options for an item (for example, a message or link in a Web page), touch and hold the item.

• Drag



To drag, press and hold your finger with some pressure before you start to move your finger. While dragging, do not release your finger until you have reached the target position.

• Pinch

In some apps (such as Maps, Browser, and Gallery), you can zoom in and out by placing two fingers on the screen at once and pinching them together (to zoom out) or spreading them apart (to zoom in).



How to add contact to your Contacts

There are some numbers that you may want to call again and again, so it makes sense to add these numbers to your contact list. You can then access these numbers quickly and easily.

1. Press Home Key > tap  > Contacts.
2. Tap  > select the place to store the contact > input the name and number or other content > Save.



How to make a call

You can make a call from Phone, also you can make a call from Contacts.



1. Press Home key > tap  > Phone.
2. Enter Dialer > input the number you want to call > tap  to dial.

How to answer or reject a call

- 1) Non lock screen to answer the call

- Tap the  icon to answer the call
- Tap the  icon to reject the call


- 2) Lock screen to answer the call

- Drag the  icon down to answer the call.
- Drag the  icon down to reject the call.


During a call

- 1) Muting a Call

- During a call, you can mute your microphone so that the person you are speaking to cannot hear you, but you can still hear him.

- Tap  to turn on or off your microphone.




- 2) Speaker On/Off

- Tap  to turn on or off the speaker.

- 3) Ending a Call


- Tap  to finish a call.


How to send a message

1. Press Home key > tap  > Messaging.
2. Tap  to create a new message.
3. Input the recipient's number or name. As you type, matching contacts will appear. Tap a suggested contact to add as a recipient. You can also tap  to select recipients from the Contacts.

4. Tap **Type message**, input the message you want to send.

Tap Menu Key to insert common phrases or contacts.

If you are sending an MMS, tap Menu Key to add a subject, or tap  to attach pictures, videos, audio, or slideshow.

5. Tap  to send your message.

Notes: Add an attachment to text message and it will be converted into an MMS automatically. Likewise if you remove all attachments and the subject from an MMS, it'll automatically become a text message.